

WSFB 50/52 & WSSH 50/52/54

WS istasyonları ve genişletme modülleri için gömme montaj ve yüzey montaj kitleri



Gömme montaj kiti
WSFB 50P



Gömme montaj kiti
WSFB 50V



Yüzey montaj kiti
WSSH 50V



Yüzey montaj kiti
WSSH 50P



Yüzey montaj kiti
WSSH 54P



Gömme montaj kiti
WSFB 52P



Gömme montaj kiti
WSFB 52V



Yüzey montaj kiti
WSSH 52V



Yüzey montaj kiti
WSSH 52P



Yağmur koruma çatısı
WSRR 50V

Gömme montaj kitleri - polikarbonat yapı

WSFB 50P "tam yükseklik" biçiminde gömme montaj takımı

WSFB 52P "yarı yükseklik" biçiminde gömme montaj takımı

Gömme montaj kitleri - darbeye karşı dayanıklı

WSFB 50V "tam yükseklik" biçiminde gömme montaj takımı

Mevcut sürümler:

WSFB 50V SS Paslanmaz çelik kaplama
WSFB 50V OR Turuncu RAL 2004

WSFB 50V SS FL "tam yükseklikte, sıva ile aynı hizada" biçiminde paslanmaz çelik gömme montaj kiti

WSFB 52V SS "yarı yükseklik" biçiminde paslanmaz çelik kaplamalı gömme montaj kiti

Yüzey montaj kitleri - polikarbonat yapı

WSFB 50P "tam yükseklik" biçiminde yüzey montaj kiti

WSSH 52P "yarı yükseklik" biçiminde yüzey montaj kiti

WSSH 54P "yarı genişlik" biçiminde yüzey montaj kiti

Yüzey montaj kitleri - darbeye karşı dayanıklı

Malzeme: Toz boyalı paslanmaz çelik. Kalınlık: 1.5 mm (0.06 in)

WSSH 50V "tam yükseklik" biçiminde yüzey montaj kiti

Mevcut sürümler:

WSSH 50V SS Paslanmaz çelik
WSSH 50V WA Beyaz alüminyum RAL 9006
WSSH 50V OR Turuncu RAL 2004
WSSH 50V OR "SOS" yazılı Turuncu RAL 2004
WSSH 50V YL EM "YARDIM" yazılı Sarı RAL 1016

WSSH 52V SS "yarı yükseklik" biçiminde yüzey montaj kiti

Yağmur koruma çatısı

WSRR 50V "tam yükseklik" biçimindeki genişleme modülleri ve darbeye dayanıklı istasyonlar için paslanmaz çelik yağmur koruma çatısı.

Gömme montaj kiti WSFB 50P

Kurulum talimatları

Kapsam


- Gömme montaj kutusu polikarbonat (boşluklu duvar tırnakları ve kapak dahil)
- Montaj çerçevesi polikarbonat (contalar ve montaj vidaları dahil)
- 3 x IP66 kablo beslemesi
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 380 g (0.84 lbs)

Boyutlar

Ölçüm birimleri mm'dir. Gömme montaj kutusu için kesit: 136 (5.36) x 252 (9.92)



WSFB 50P gömme montaj kiti montajı



- 1 **Connection spacer (with gaskets) for connecting two flush mount boxes and for cable feed through**
 - When mounting the device to the top or bottom side of a WS station or an expansion module, the connection spacer in the extent of supply has to be mounted to the outer expansion openings (see above)
 - Make sure the connection spacer is snapped-in correctly in the expansion opening!
- 2 **IP66 cable feed through**
 - The cable feed through can be put in after breaking out the expansion openings (installation cable feed through see above)
- 3 **Flush mount box (polycarbonate)**
 - For cavity wall mounting or installation in a desk, use avity wall claws (wall thickness: 2 to 30 mm / 0.08 to 1.18 in)
- 4 **Gasket**
- 5 **Mounting frame (polycarbonate)** 5a **Top gasket for mounting frame (mounted ex works)**
 - Screw mounting frame onto the flush mount box (screws in extent of supply)
- 6 **Front panel (polycarbonate) with station electronics**
 - Mounting: Press the front panel onto the mounting frame
 - Dismounting: Pull off the front panel

Gömme montaj kiti WSFB 52P

Kurulum talimatları

Kapsam


- Gömme montaj kutusu polikarbonat (boşluklu duvar tırnakları ve kapak dahil)
- Montaj çerçevesi polikarbonat (contalar ve montaj vidaları dahil)
- 3 x IP66 kablo beslemesi
- 2 x bağlantı parçası (conta dahil)
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 230 g (0.5 lbs)

Boyutlar

Ölçüm birimleri mm'dir. Gömme montaj kutusu için kesit: 136 (5.36) x 112 (4.41)



WSFB 52P gömme montaj kiti montajı



- 1 **Connection spacer (with gaskets) for connecting two flush mount boxes and for cable feed through**
 - When mounting the device to the top or bottom side of a WS station or an expansion module, the connection spacer in the extent of supply has to be mounted to the outer expansion openings (see above)
 - Make sure the connection spacer is snapped-in correctly in the expansion opening!
- 2 **IP66 cable feed through**
 - The cable feed through can be put in after breaking out the expansion openings (installation cable feed through see above)
- 3 **Flush mount box (polycarbonate)**
 - For cavity wall mounting or installation in a desk, use avity wall claws (wall thickness: 2 to 30 mm / 0.08 to 1.18 in)
- 4 **Gasket**
- 5 **Mounting frame (polycarbonate)** 5a **Top gasket for mounting frame (mounted ex works)**
 - Screw mounting frame onto the flush mount box (screws in extent of supply)
- 6 **Front panel (polycarbonate) with station electronics**
 - Mounting: Press the front panel onto the mounting frame
 - Dismounting: Pull off the front panel

Gömme montaj kiti WSFB 50V

Kurulum talimatları

Kapsam


- Gömme montaj kutusu polikarbonat (boşluklu duvar tırnakları ve kapak dahil)
- Montaj çerçevesi metal (montaj vidaları ve conta dahil)
- 3 x IP66 kablo beslemesi
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 540 g (1.2 lbs)

Boyutlar

Ölçüm birimleri mm'dir. Gömme montaj kutusu için kesit: 136 (5.36) x 252 (9.92)



WSFB 50V gömme montaj kiti montajı



1 Connection spacer (with gaskets) for connecting two flush mount boxes and for cable feed through

- When mounting the device to the top or bottom side of a WS station or an expansion module, the connection spacer in the extent of supply has to be mounted to the outer expansion openings (see above)
- Make sure the connection spacer is snapped-in correctly in the expansion opening!

2 IP66 cable feed through

- Put in cable feed through after breaking out the expansion openings (installation cable feed through, see above)

3 Flush mount box (polycarbonate)

- For cavity wall mounting or installation in a panel, use cavity wall claws (wall thickness: 2 – 30 mm / 0.08 – 1.18 in)

4 Mounting frame (metal) incl. gasket

- Screw mounting frame onto the flush mount box (screws in extent of supply)

5 Front panel (metal) with station electronics

- Screw front panel onto mounting frame

Gömme montaj kiti WSFB 50V FL

Kurulum talimatları

Kapsam


- Metal çerçeveli gömme montaj kutusu polikarbonat (kapak dahil)
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 540 g (1.2 lbs)

Boyutlar

Ölçüm birimleri mm'dir.



WSFB 50V FL gömme montaj kiti montajı

**DİKKAT:**

Doğru montaj yönüne dikkat edin.

- 1 **Flush mount box (polycarbonate) with flush mount frame (metal)**
→ Install the flush mount box by moulding into plaster or concrete.
Do not remove plaster cover until the flush mount box is mounted.
- 2 **Front panel (metal) with electronics and gasket**
→ Screw front panel onto flush mount frame

Gömme montaj kiti WSFB 52V

Kurulum talimatları

Kapsam


- Gömme montaj kutusu polikarbonat (boşluklu duvar tırnakları ve kapak dahil)
- Gömme montaj çerçevesi metal ve conta
- 3 x IP66 kablo beslemesi
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 360 g (0.79 lbs)

Boyutlar

Ölçüm birimleri mm'dir. Gömme montaj kutusu için kesit: 136 (5.36) x 112 (4.41)



WSFB 52V gömme montaj kiti montajı



- 1 **Connection spacer (with gaskets) for connecting two flush mount boxes and for cable feed through**
 - When mounting the device to the top or bottom side of a WS station or an expansion module, the connection spacer in the extent of supply has to be mounted to the outer expansion openings (see above)
 - Make sure the connection spacer is snapped-in correctly in the expansion opening!
- 2 **IP66 cable feed through**
 - Put in cable feed through after breaking out the expansion openings (installation cable feed through, see above)
- 3 **Flush mount box (polycarbonate)**
 - For cavity wall mounting or installation in a panel, use cavity wall claws (wall thickness: 2 – 30 mm / 0.08 – 1.18 in)
- 4 **Mounting frame (metal) incl. gasket**
 - Screw mounting frame onto the flush mount box (screws in extent of supply)
- 5 **Front panel (metal) with station electronics**
 - Screw front panel onto mounting frame

Yüzey montaj kiti WSSH 50P

Kurulum talimatları

Kapsam


- Yüzey montaj kutusu (contalar dahil)
- 3 x IP66 kablo beslemesi
- Duvara montaj kiti (vidalar, dübeller, conta halkaları ve rondelalar)
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 300 g (0.66 lbs)

Boyutlar

Ölçüm birimleri mm'dir.



WSSH 50P yüzey montaj kiti montajı



- 1 **Gasket for expansion opening at the rear of the housing**
 - The expansion openings have to be broken out with a blunt object at the outer notch!
 - If the rear opening is used, attach the gasket at the backside of the flush mount box (see dimensions).
- 2 **Connection spacer (with gaskets) for connecting two surface mount boxes and for cable feed through**
 - The expansion openings have to be broken out with a blunt object at the outer notch!
 - If possible, two connection spacers shall be used per expansion.
 - Make sure the connection spacer is snapped-in correctly in the expansion opening!
- 3 **IP66 cable feed through**
 - The cable feed through can be put in after breaking out the expansion openings (installation cable feed through see above).
- 4 **Surface mount box (polycarbonate)** 4a **Top gasket for surface mount box (mounted ex works)**
 - Mounting via wall mounting kit (screws, dowels, gasket rings and washers) – in extent of supply.
 - Washer and gasket ring have to be mounted inside the surface mount box.
- 5 **Front panel (polycarbonate) with station electronics**
 - Mounting: Press the front panel onto the surface mount box
 - Dismounting: Pull off the front panel.

Yüzey montaj kiti WSSH 52P

Kurulum talimatları

Kapsam


- Yüzey montaj kutusu polikarbonat (contalar dahil)
- 2 x bağlantı parçası (conta dahil)
- 3 x IP66 kablo beslemesi
- Duvara montaj kiti (vidalar, dübeller, conta halkaları ve rondelalar)
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 150 g (0.33 lbs)

Boyutlar

Ölçüm birimleri mm'dir.



WSSH 52P yüzey montaj kiti montajı



- 1 **Gasket for expansion opening at the rear of the housing**
 - The expansion openings have to be broken out with a blunt object at the outer notch!
 - If the rear opening is used, attach the gasket at the backside of the flush mount box (see dimensions).
- 2 **Connection spacer (with gaskets) for connecting two surface mount boxes and for cable feed through**
 - The expansion openings have to be broken out with a blunt object at the outer notch!
 - When mounting the device to the top or bottom side of a WS station or an expansion module, the connection spacer in the extent of supply has to be mounted to the outer expansion openings (see above).
 - Make sure the connection spacer is snapped-in correctly in the expansion opening!
- 3 **IP66 cable feed through**
 - The cable feed through can be put in after breaking out the expansion openings (installation cable feed through see above).
- 4 **Surface mount box (polycarbonate)** 4a **Top gasket for surface mount box (mounted ex works)**
 - Mounting via wall mounting kit (screws, dowels, gasket rings and washers) – in extent of supply
 - Washer and gasket ring have to be mounted inside the surface mount box.
- 5 **Front panel (polycarbonate) with station electronics**
 - Mounting: Press the front panel onto the surface mount box
 - Dismounting: Pull off the front panel.

Yüzey montaj kiti WSSH 54P

Kurulum talimatları

Kapsam


- Yüzey montaj kutusu polikarbonat (contalar dahil)
- 2 x bağlantı parçası (conta dahil)
- 1 x IP66 kablo beslemesi
- Duvara montaj kiti (vidalar, dübelller, conta halkaları ve rondelalar)
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık


Paketleme dahil ağırlık: yaklaşık 160 g (0.35 lbs)

Boyutlar

Ölçüm birimleri mm'dir.



WSSH 54P yüzey montaj kiti montajı



- 1 **Gasket for expansion opening at the rear of the housing**
 - The expansion openings have to be broken out with a blunt object at the outer notch!
 - If the rear opening is used, attach the gasket at the backside of the flush mount box (see dimensions).
- 2 **Connection spacer (with gaskets) for connecting two surface mount boxes and for cable feed through**
 - The expansion openings have to be broken out with a blunt object at the outer notch!
 - If possible, two connection spacers shall be used per expansion.
 - Make sure the connection spacer is snapped-in correctly in the expansion opening!
- 3 **IP66 cable feed through**
 - The cable feed through can be put in after breaking out the expansion openings (installation cable feed through see above).
- 4 **Surface mount box (polycarbonate)**
 - Mounting via wall mounting kit (screws, dowels, gasket rings and washers) – in extent of supply.
 - Washer and gasket ring have to be mounted inside the surface mount box.

Yüzey montaj kiti WSSH 50V

Kurulum talimatları

Kapsam


- Yüzeye montaj kutusu metal (6 x boş fiş dahil)
- Polikarbonat kutu
- 3 x IP66 kablo beslemesi
- Duvara montaj kiti (vidalar, dübeller, conta halkaları ve rondelalar)
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık

Paketleme dahil ağırlık: yaklaşık 945 g (2.08 lbs)

Boyutlar


Ölçüm birimleri mm'dir.




WSSH 50V yüzey montaj kiti montajı

DİKKAT:

- Yüzeye montaj kutusu için boş fişler (tedarik kapsamında), muhafaza açılmadan çıkarılamaz.



- 1 **Surface mount box (metal)**
→ Mounting via wall mounting kit (screws and dowels) – in extent of supply
- 2 **IP66 cable feed through**
→ The cable feed through can be put into the plastic box after breaking out the expansion openings (only one cable per feed through).
- 3 **Polycarbonate box**
→ Press the polycarbonate box into the surface mount box
- 4 **Front panel (metal) with station electronics**
→ Screw the front panel onto the surface mount box



Yüzey montaj kiti WSSH 52V

Kurulum talimatları

Kapsam


- Yüzeye montaj kutusu metal (4 x boş fiş dahil)
- Polikarbonat kutu
- 3 x IP66 kablo beslemesi
- Duvara montaj kiti (vidalar, dübelller, conta halkaları ve rondelalar)
- Kablo sabitleme braketleri (vidalar dahil)
- Kısa referans

Ağırlık

Paketleme dahil ağırlık: yaklaşık 635 g (1.4 lbs)

Boyutlar


Ölçüm birimleri mm'dir.




WSSH 52V yüzey montaj kiti montajı

DİKKAT:

Yüzeye montaj kutusu için boş fişler (tedarik kapsamında), muhafaza açılmadan çıkarılamaz.



- 1 **Surface mount box (metal)**
→ Mounting via wall mounting kit (screws and dowels) – in extent of supply
- 2 **IP66 cable feed through**
→ The cable feed through can be put into the plastic box after breaking out the expansion openings (installation cable feed through see picture to the right).
- 3 **Polycarbonate box**
→ Press the polycarbonate box into the surface mount box
- 4 **Front panel (metal) with station electronics**
→ Screw the front panel onto the surface mount box



Yağmur koruma çatısı WSRR 50V

Kurulum talimatları

Kapsam


- Yağmur koruma çatısı
- Sabitleme vidaları
- Kısa referans

Ağırlık

Paketleme dahil ağırlık: yaklaşık 466 g (1.03 lbs)

Boyutlar


Ölçüm birimleri mm'dir.



WSRR 50V yağmur koruma çatısı montajı

DİKKAT:

Yağmura karşı koruyucu çatı, yüzey ve gömme montajda, darbeye karşı dayanıklı istasyonlar ve genişleme modülleri için kullanılabilir. Aşağıdaki çizim yağmur koruma çatısı WSRR 50V'nin WSSH 50V yüzey montaj kitine kurulumunu göstermektedir.



- İstasyon ön panelinin monte edildiği vidaları çıkarın.
- Ardından, yağmur koruma çatısını, istasyon ön paneli ile birlikte yüzey montaj kutusuna veya gömme montaj çerçevesine, tedarik miktarındaki sabitleme vidalarını kullanarak vidalayın (yukarıya bakın).

Kalite test edildi. Güvenilir. Akıllı

COMMEND ürünleri Salzburg, Avusturya'da Commend International tarafından geliştirildi ve üretildi.

Geliştirme ve üretim süreçleri

EN ISO 9001:2008'e uygun olarak belgelendirilmiştir.



Burada yer alan teknik veriler yalnızca bilgilendirme amacıyla sağlanmıştır ve yasal olarak bağlayıcı değildir. Teknik veya başka şekilde değişebilir. IoIP®, OpenDuplex® ve Commend® Commend International GmbH tarafından tescilli ticari markalardır. Diğer tüm markalar veya ürün adları, ilgili mal sahibinin ticari markaları veya tescilli ticari markalarıdır ve özel olarak ayrılmış değildir.

Dünya çapında güçlü bir ağı

COMMEND, tüm dünyadaki Commend Partners tarafından temsil edilmekte ve kişiye özel Interkom çözümleri ile güvenliği ve iletişimi geliştirmeye yardımcı olmaktadır.

www.commend.com